TOPFIELD

TRF-7260

User Reference

High Definition

Digital Terrestrial Receiver

Personal Video Recorder

Default PIN: 0000

DVB
Digital Video
Broadcasting

.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lightning flash with arrowhead symbol, in an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to a person.

The exclamation point, in an equilateral triangle, is intended to alert the user to the presence of important operation and maintenance instructions in the literature accompanying the product.

Precautions

- Read, keep and follow these instructions.
- Read all warnings.
- Clean with a dry cloth only.
- Do not block any of the ventilation openings.
- Do not install near any heat sources or in direct sunlight as this will impair cooling.
- Do not operate this product near water. Do not place any of the objects filled with liquids, such as vases on this unit.
- Do not try to change the plug or defeat its safety purpose. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- This product is designed for indoor use only.
- Place the digital receiver on a firm and level surface.
- Do not lay any objects such as magazines on this unit.
- Do not overload power outlets. Doing so may result in a risk of fire or electrical shock.
- Never open this unit's casing under any circumstances, or the warranty will be void.
- Unplug this unit during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the unit, the unit became wet from rain or moisture, does not operate normally, or has been dropped.
- Batteries, including those which contain no heavy metals, may not be disposed with other household wastes. Please dispose of used batteries in an environmentally sound manner. Find out the legal regulations which apply in your area.

About this user guide

Thank you for purchasing our digital receiver. Please read this user guide carefully before you use the digital receiver and keep it handy for future reference.

This User Guide covers the model TRF-7260 .

- Illustrations pictured in this manual may not be exactly the same as the actual product.
- The screenshots used in this manual may not be exactly the same as those you see on the actual on-screen displays.
- Designs and specifications of the digital receiver and other accessories are subject to change without any notice in order to introduce new features or improve the functionality of the product.

The TF RCU app for iPhone

The RCU application is available to download from the App Store (currently for iPhone only). Download the TF RCU app to control this unit with your smart phone.

* iPhone and App Store are registered trademarks of Apple, Inc.

Compatible RCU support

The TRF-7260 supports compatible RCU usage for the PVR set.

Menu > Settings > Miscellaneous > Type of RCU

* The RCU code is required for this feature.

** Please visit http://topfield.com.au for more information.

Contents

Contents v

1 Introduction 1
- 1.1 Features . . . 1
- 1.2 Controlling the digital receiver . . . 2
  - 1.2.1 Front panel . . . 2
  - 1.2.2 Remote control . . . 3

2 Setup 5
- 2.1 Unpacking . . . 5
- 2.2 Safety precautions . . . 5
- 2.3 Rear panel connections . . . 6
- 2.4 Connecting up your digital receiver . . . 7
  - 2.4.1 Connecting to the antenna . . . 8
  - 2.4.2 Connecting to your television set . . . 8
- 2.5 Switching ON for the first time . . . 10

3 Service Search 11
- 3.1 Searching for broadcasting services . . . 11
- 3.2 Reset to factory settings . . . 12
- 3.3 Store/Restore user settings . . . 12
- 3.4 Reset service list . . . 13

4 Preference Settings 14
- 4.1 Video and audio settings . . . 14
  - 4.1.1 High definition television . . . 14
  - 4.1.2 Television aspect ratio . . . 15
  - 4.1.3 Audio mode . . . 16
- 4.2 Local time setting . . . 16
- 4.3 Parental control . . . 18
- 4.4 Options for recording . . . 19

4.5 Options for playback . . . 19
4.6 Options for on-screen display . . . 20
4.7 Options for the front display . . . 20
4.8 Options for Photo Album . . . 21
4.9 Options for standby mode . . . 21

5 Every Day Use **22**
5.1 Volume control . . . 22
5.2 Watching television . . . 22
5.2.1 The services list . . . 22
5.2.2 The favourite service list . . . 23
5.2.3 Viewing programme information . . . 24
5.2.4 Selecting audio tracks . . . 24
5.2.5 Selecting subtitle tracks . . . 24
5.3 Viewing electronic programme guide . . . 25
5.4 Using time-shift . . . 26

6 Organising Services **28**
6.1 Editing the favourite lists . . . 28

7 Recording and Playback **30**
7.1 Recording a programme . . . 31
7.1.1 Instant recording . . . 31
7.1.2 Timer recording . . . 33
7.1.3 Scheduling recordings using the programme guide . . . 34
7.1.4 Recording a time-shifted programme . . . 36
7.2 File archive . . . 36
7.2.1 To delete a recording . . . 36
7.2.2 To sort recordings . . . 37
7.2.3 To lock a recording . . . 37
7.2.4 To rename a recording . . . 37
7.2.5 To make a new folder . . . 37
7.2.6 To move a recording to another folder . . . 37
7.3 Playing back a recording . . . 38
7.3.1 To navigate using the progress bar . . . 38
7.3.2 To play in slow motion . . . 39
7.3.3 To play in fast motion . . . 39
7.3.4 To make a bookmark . . . 39
7.4 Copying a recorded file . . . 40
7.5 Formatting the hard disk . . . 40

8 Accessing via Network **41**
8.1 Configuring the router . . . 42
8.1.1 To access within the local area network . . . 42
8.1.2 To access over the Internet . . . 42

8.2 Network setup 44
8.2.1 For a wired connection 44
8.2.2 For a wireless connection 44
8.3 Accessing the web server 45
8.4 Accessing the FTP server 47

9 Topfield Application Program **49**

10 Firmware Update **52**
10.1 From a memory stick 52
10.2 From the firmware server via the Internet 53

A Troubleshooting **54**

Chapter 1

Introduction

The TRF-7260 digital receiver is fully compliant with the international Digital Video Broadcasting (DVB) standard, and thus is able to receive digital broadcasts of that standard. For its operation you need an antenna, which must be installed appropriately.

NOTE

The frequency in digital broadcasting is usually called transponder or multiplex. To reduce confusion in this manual, the word **service** is preferably used than **channel** as a term to indicate one television or radio broadcast.

1.1 Features

This digital receiver has the following features:

- Can store up to 2,000 television and radio services.
- Can create lists of your favourite services.
- You can record programmes to the internal HDD.
- Time-shift is a special technical feature available on this digital receiver. You can pause a programme you are watching and resume it again at a later time. Then you can quickly go to any part of the current programme by fast forward or rewind search.
- If you have an external hard drive connected to the digital receiver via USB, you can record programmes into it.

1.2 Controlling the digital receiver

You can operate the digital receiver with the remote control or the buttons on the front panel.

NOTE

Even when you are not using the digital receiver, you should keep it plugged into a wall socket to be in standby mode so that it can run timer events at any time.

1.2.1 Front panel

The front panel of the digital receiver has buttons to control the digital receiver, specific lights and a display to indicate its status.



STANDBY	lights up while the digital receiver is in standby mode.
⏻/I	switches the digital receiver between standby mode and active mode.
MENU	displays the main menu. Also, returns to previous menu from a submenu.
▼, ▲CHANNEL	switch to the previous or next service. Also, navigate in menus and interactive screens.
◀, ▶VOLUME	decrease or increase the volume. Also, change values for menu options.
OK	displays the services list. See §5.2.1 for more details. Also, selects a menu item.

1.2.2 Remote control

1 switches the digital receiver between standby mode and active mode.

2 mutes the sound. Press again to switch it back on.

3 V.Format changes video resolution.

4 A/R changes aspect ratio.

5 AUX not used in this model.

6 switches over between television services and radio services.

7 Numeric buttons are used to enter a service number for service change or to to specify values for menu options.

8 switches over between the current service and the previously viewed one.

9 displays the service information box.
Also, displays more information about a programme.

10 selects audio track or sound mode.

11 not used in this model.

12 selects a subtitle track.

13 sets sleep timer in 10 minute increments.

14 MENU displays the main menu.
Also, returns to the previous menu from a submenu.

15 GUIDE displays the electronic programme guide.

16 ▼, ▲ allow you to choose an item from the menu.
Also, navigate through the electronic programme guide or interactive services.

17 ◀, ▶ allow you to change the options for a menu item.
Also, navigate through the electronic programme guide or interactive services.

18 (OK LIST) displays the services list. Also, selects menu items.

19 [EXIT] exits a menu or hides on-screen information.

20 [LIST] displays the list of recorded programmes that are stored in the internal hard drive.

21 [V−], [V+] decrease or increase the volume.

22 [P−], [P+] switch to the previous/next service.

23 ⏪ starts reverse playback. Subsequent presses increase the rewind speed.

24 ⏸ pauses live television or playback of a recorded programme.

25 ▶ resumes normal playback speed, or displays the progress bar for navigation on playback or time-shift. To play a recorded programme, see button **30** 📺.

26 ⏩ starts fast forward playback. Subsequent presses increase the playback speed.

27 ⏺ starts recording.

28 ⏹ stops playback, recording, or jumps back to live television from time-shifted television.

29 ⏯ starts slow motion playback. Subsequent presses change the playback speed.

30 📺 displays the list of recorded programmes that are stored in the internal hard drive.

31 ⏭⏮ has different functions per menu.

32 ⏮ jumps back to the beginning of the recording on playback.

33 ⏭ jumps to the end of the recording on playback.

34 [SAT] displays connected device list.

35 [F1] has different functions per menu.

36 [F2] makes a bookmark on playback or time-shift.

37 [F3] jumps to next bookmark position.

38 [F4] edits a recording.

39 📺 not used in this model.

40 [FAV] displays the favourite list.

Functions of the colour buttons will be guided on the screen.

NOTE

In order to use the Topfield RCU for your TV, refer to the Universal RCU setup for TV guide: Menu > Information.

Chapter 2

Setup

2.1 Unpacking

Before going any further, check that you have received the following items with the digital receiver.

- Remote control
- Two batteries for the remote control (AAA 1.5 V)
- One HDMI cable
- A copy of the User Manual

NOTE

Accessories may vary according to your local area.

2.2 Safety precautions

Please read carefully the following safety precautions.

- The mains voltage must range between 90 and 250 volts. Check it before plugging the digital receiver to the wall socket. For the power consumption of the digital receiver, refer to Table 2.1.
- The wall socket should be near the equipment. Do not run an extension lead to the unit.
- The mains plug shall remain readily operable so that it can be removed easily to disconnect the power.
- When placed in a cabinet, make sure there is a minimum space of 10 centimetres around it. For the physical specification of the digital receiver, refer to Table 2.2.

- Protect the power cord from being walked on or pinched. If the cord is damaged, do not use the digital receiver and get the cord replaced.
- Refer all servicing to a qualified service technician.
- To maintain proper ventilation, always leave sufficient space around the digital receiver.

Table 2.1: Power specification

Input voltage	90 to 250 V AC, 50/60 Hz
Power consumption	30 W at maximum in active
	Under 5 W in passive standby

Table 2.2: Physical specifications

Size	340× 60× 265 mm
Weight(Net)	3.1 kg
Operating temperature	0 to 45 °C
Storage relative humidity	5 to 90 %

2.3 Rear panel connections



Check what connections your television set has in comparison with the digital receiver.

ANT IN	Terrestrial broadcasting signal input socket (5V, Max.100mA)
ANT OUT	Terrestrial broadcasting signal output socket through the ANT IN socket for other receiver
VIDEO	Composite video output socket for the television set (yellow)
AUDIO R/L	Stereo audio output socket for television or audio receiver (white/red)

Y/Pb/Pr	Component video output socket for the television set (green/blue/red)
S/PDIF	Digital audio output socket for the audio-video receiver
HDMI	Audio and video output socket for high definition television set
LAN	Local area network port
USB	USB port for firmware update and data transfer

Table 2.3: Connectors specifications

HDMI	High definition video output
	Left & right audio output
	Digital audio output
YPbPr	Component video output
VIDEO	Composite video (CVBS) output
AUDIO	Left & right audio output
S/PDIF	Digital audio output
LAN	10/100 Ethernet
USB	2.0 Host (5 V DC, 500 mA)

2.4 Connecting up your digital receiver

There are several ways to set up the digital receiver. Set up the digital receiver suitably to your television and other devices. If you have any problem with your setup or need help, contact your dealer.

WARNING

Connect any components before plugging the power cord into the wall outlet. Always turn off the product, TV and other components before you connect or disconnect any cables.

NOTE

If you encounter any problems setting up your product, please contact your local retailer.

2.4.1 Connecting to the antenna



Whatever sort of connection you have between the digital receiver and the television, you need to connect the digital receiver to the antenna so that it can receive digital television broadcasts. Connect the antenna cable to the ANT IN connector. If you have another digital receiver, you may link it from the ANT OUT connector.

NOTE

ANT OUT may also be linked to your television, VCR, or DVD recorder to loop an analogue signal.

2.4.2 Connecting to your television set

For all the following connections of the digital receiver, we recommend you to use the first connector to get the best picture quality. If your television does not have a matching connector, then use the next connector in the following order for a better picture quality.

1. HDMI connector (HDMI)
2. Component connector (YPbPr)
3. Composite connector (VIDEO)

You should configure audio and video settings after connecting up the digital receiver. See §4.1 for a detailed description.

To use the HDMI output



If you have a high definition television set, you should use an HDMI cable for best results. Plug one end of the cable into the HDMI socket on the digital receiver, and plug the other end into the matching socket on your television.

In this case, you do not have to make audio connection because it can output stereo audio or digital audio as well.

To use the Component video output



You need to obtain a Component video cable (RCA cable) to use the Component video output. Plug one ends of the cable into the Y (green), Pb (blue) and Pr (red) sockets on the digital receiver, and plug the other ends into the matching sockets on your television.

NOTE

Remember to plug in the additional white and red audio cables from the digital receiver to the back of your television.

To use the Composite video output



You need to obtain a Composite video cable (RCA cable) to use the Composite video output. Plug one end of the cable into the VIDEO (yellow) socket on the digital receiver, and plug the other end into the matching socket on your television.

NOTE

You cannot view high definition video by means of the Composite video output.

To make the audio connection



You need to obtain an audio cable (RCA cable) to link the audio connectors. Plug one end of the cable into the AUDIO L (white) and AUDIO R (red) sockets on the digital receiver, and plug the other ends into the matching sockets on your television or audio-video receiver.



To enjoy Dolby Digital audio, your television or audio-video receiver must be able to decode Dolby Digital audio, and you need to obtain a S/PDIF cable.

Plug one end of the cable into the S/PDIF socket on the digital receiver, and plug the other end into the matching socket on your audio-video receiver.

2.5 Switching ON for the first time

Now that you have your digital receiver connected, you should plug it into a wall socket. Ensure that your television set is turned on and on the correct video channel so that you will be able to see the display from the digital receiver.

Press the button on the top left corner on the remote control. In a little time, you may see a picture displaying a menu.

If you do not see a picture, try pressing the VF button on the remote control. If after several tries you still get no picture, check that the television is set to the correct input. If the picture is good, you can skip to §3.1 to search for available television and radio services.

Otherwise, you may need to temporarily connect the Composite video connector (VIDEO) to your television set so that you can see the menu in order to configure the video settings.

CAUTION

If the digital receiver no longer reacts properly to the remote control commands, the batteries may be flat. Be sure to replace only with 1.5 V AAA size batteries, and observe the following precautions.

- Do not mix different types of batteries, or new and old batteries.
- Do not use rechargeable batteries.
- Do not recharge the old batteries.
- In order to avoid any risk of explosion, observe the polarities indicated inside the battery compartment.
- Do not subject to excessive heat such as the sun and fire.
- If you are not using the remote control for a long period of time, remove the batteries. The manufacturer accepts no liability for the damage resulting from leaking batteries.
- Batteries, including those which contain no heavy metals, may not be disposed with other household wastes. Please dispose of used batteries in an environmentally sound manner. Find out the legal regulations which apply in your area.

Chapter 3

Service Search

After connecting up the digital receiver, you will need to perform a service search.

NOTE

If there is no service stored, you will be not able to access all menus. A SERVICE is another name for a CHANNEL.

3.1 Searching for broadcasting services



To perform service search, select the Installation > Searching menu. You should see a screen like the left figure.

You should set the Search Mode option to Auto for the first time after connecting up the digital receiver.

You may choose to only search for the services of a specific transponder since more than one service are provided via each transponder. Set the Search Mode option to Manual, then select your desired transponder at the Channel option. The number ranges from 6 to 12 in VHF and 28 to 69 in UHF.

It is possible to search single service in a certain transponder only if you know the desired service's audio and video packet identification (PID). Set the Search Mode option to Advanced, then the PID option becomes enabled. Specify the PIDs of your desired service with the numeric buttons.

To start service search, move down to the Start Search item, and press the OK button. The digital receiver will start to search for services. It is common for no channels to be found until quite late in the process. When the scan is complete, you will see a message telling you how many services have been found. Press the OK button to save the list.

3.2 Reset to factory settings

The digital receiver maintains the following data:

- Services list
- Favourite list
- Timer list
- Preference settings

You can reset all data of the digital receiver. Select the Installation > System Recovery > Factory Setting menu, and then you get asked for confirmation. With the choice of Yes, the services list, favourite list and timer list will all be cleared, and preference options will be reset to the manufacturer's factory settings.

NOTE

A factory reset will not delete any recorded programmes. However, you have to search services again after a factory reset.

3.3 Store/Restore user settings

You can store your own data including the following:

- Services list
- Favourite lists
- Preference settings

Also you can restore them at any time.

To store your data, select the Installation > System Recovery > Store System Data menu, then you get asked for confirmation. If you select Yes, your data will be stored. Whenever you store your data, they are all overwritten. To restore your data, select the Installation > System Recovery > Recover System Data menu, then you get asked for confirmation. With the choice of Yes, your data will be restored.

3.4 Reset service list

If you only want to clear the service list, select Installation > System Recovery > Reset Service List , then you get asked for confirmation. With the choice of Yes, the services list will be cleared. After this, you have to do service search again.

Chapter 4

Preference Settings

4.1 Video and audio settings

You have to configure the video and audio settings appropriately for your television set and other devices. Select the Settings > A/V Output menu. You should see a screen like the left figure.

4.1.1 High definition television

The digital receiver supports various video resolutions from 576 to 1080. In general, a resolution of 720 or more is considered high definition. The higher the resolution is, the better the quality is. However, if your television set does not support high definition, you cannot enjoy high definition quality picture.

Set the Video Format option as you desire. If you set this option to 576P, the digital receiver will present even high definition programmes in resolution of 576. On the contrary, if you set it to 1080I, the digital receiver will present even standard definition programmes in resolution of 1080.

While watching television you can change the resolution with the (VF) button. Whenever you press it, the video resolution is changed in turn.

NOTE

You can enjoy only standard definition video with the Composite video output (VIDEO).

4.1.2 Television aspect ratio

If you have a wide-screen television, set the TV Aspect Ratio option to 16:9.



You can enjoy both wide-screen programmes and normal-screen programmes with your wide-screen television as the above figures show. To watch normal-screen programmes in full screen like the left figure, set the Display Format option to Full. Normal-screen pictures then will be inflated to fit to the width of the wide screen. Otherwise, to watch them in the original ratio like the right figure, set it to Center. If you have a normal-screen television, set the TV Aspect Ratio option to 4:3.

You cannot fully enjoy wide-screen programmes with your normal-screen television as the above figures show. The left figure shows a normal picture displayed in the normal screen. To watch wide-screen programmes in the shape like the centre figure, set the Display Format option to Letter Box. Wide-screen pictures then will be reduced to fit to the width of the normal screen. Otherwise, to watch them in the shape like the right figure, set it to Center extract. Then wide-screen pictures will be cut out on the left and right sides equally to fit to the width of the normal screen.

4.1.3 Audio mode

Basically, there are two audio sources as you can find two audio sockets on the back panel of the digital receiver. You can enjoy only one source or both of them in either stereo or mono. Set the Sound Mode option as you desire.

Apart from this setting, you can change the sound mode with the button. See §5.2.4 for a detailed description.

The digital receiver can output two types of digital audio signals via the S/PDIF output. One is an encoded signal, and the other is a decoded signal. If you have the digital receiver linked to your audio-video receiver via the S/PDIF output, you have to set the Dolby Digital option to PCM, which means that the digital receiver will output encoded Dolby Digital audio without decoding so that your audio-video receiver can decode it. Otherwise, set it to multi-channel, then the digital receiver will output decoded Dolby Digital audio, scaling it down to two channels.

NOTE

Only if the service you are currently watching provides a Dolby Digital audio track, you can enjoy Dolby Digital sound.

4.2 Local time setting

You should set your local time for timer events.

Select the Settings > Time menu. You can set the clock manually or by Greenwich Mean Time (GMT). To use Greenwich Mean Time, take the following steps:

1. Set the Mode to Auto, then the Time Offset will be enabled.
2. Set the Time Offset option to the time difference between your time zone and GMT referring to Table 4.1.
3. Make sure the correct time is displayed on the Local Time area.

To set the local time manually, set Mode to Manual and enter the correct time to the Local Time option with the numeric buttons. The time format is *day/month/year 24-hour:minute*. To change the time format to 12-hour format, set the Time Format option to 12 Hours.

If daylight saving time is observed in your state at the moment, set the Daylight Saving Time option to On.

NOTE

Daylight saving time adds one hour to the time when the option is set to On. When setting the time offset from Greenwich Mean Time, make sure that time offset does not include daylight saving time.

Table 4.1: Time offset table

Time offset	City
GMT − 12:00	Eniwetok, Kwajalein
GMT − 11:00	Midway Island, Samoa
GMT − 10:00	Hawaii
GMT − 09:00	Alaska
GMT − 08:00	Pacific Time US, Canada
GMT − 07:00	Mountain Time US, Canada
GMT − 06:00	Central Time US, Canada, Mexico City
GMT − 05:00	Eastern Time US, Canada, Bogota, Lima
GMT − 04:00	Atlantic Time Canada, La Paz, Dominican Republic
GMT − 03:30	Newfoundland
GMT − 03:00	Brazil, Georgetown, Buenos Aires
GMT − 02:00	Mid-Atlantic
GMT − 01:00	Azores, Cape Verde Islands
GMT	London, Lisbon, Casablanca
GMT + 1:00	Paris, Brussels, Copenhagen, Madrid
GMT + 2:00	South Africa, Kaliningrad
GMT + 3:00	Baghdad, Riyadh, Moscow, St. Petersburg
GMT + 3:30	Tehran
GMT + 4:00	Abu Dhabi, Muscat, Baku, Tbilisi
GMT + 4:30	Kabul
GMT + 5:00	Ekaterinburg, Islamabad, Karachi, Tashkent
GMT + 5:30	Bombay, Calcutta, Madras, New Delhi
GMT + 6:00	Almaty, Dhaka, Colombo
GMT + 7:00	Bangkok, Hanoi, Jakarta
GMT + 8:00	Beijing, Perth, Singapore, Hong Kong
GMT + 9:00	Tokyo, Seoul, Osaka, Sapporo, Yakutsk
GMT + 9:30	Adelaide, Darwin
GMT + 10:00	Eastern Australia, Guam, Vladivostok
GMT + 11:00	Magadan, Solomon Islands, New Caledonia
GMT + 12:00	Fiji, Auckland, Wellington, Kamchatka

4.3 Parental control

In general, television programmes are classified according to the level of violence, nudity and language of their content. When you are watching a programme, you can check its programme classification on the information box. For the information box, see §5.2.3. You can prevent your children from watching specific programmes by specifying a maximum permissible level. Select the Settings > Parental Control menu. You will be asked for your Personal Identification Number (PIN). The number is initially set to '0000' as default.

To block programmes with undesired content for family viewing, set the Censorship option to your desired level among the following:

No block restricts no prorgramme.

Total block restricts every programme, even those with no programme classification.

G restricts to G or above. G rated programmes are suitable for all audiences.

PG restricts to PG or above rated programmes. PG stands for *Parental Guidance*, the content of which is mild.

M restricts to M or above rated programmes. M stands for *Mature*, the content of which is moderate in impact.

MA restricts to MA or above rated programmes. MA stands for *Mature Audience*, the content of which is strong.

R restricts to R rated programmes. R stands for *Restricted to adults* aged 18 years or over, the content of which is very strong.

AV restricts to AV rated programmes. AV stands for *Adult Viewing*, the content of which is deep hardcore.

NOTE

If a programme has no rating information, your censorship setting will not take effect.

If anyone is trying to watch a programme that is of or above the censorship setting, the person has to enter the personal identification number to override. To change the number, select the Change PIN Code menu, then a box pops up, asking a new PIN. Enter a desired number twice for confirmation.

You can also restrict uses of some menus. Selecting the Access Control menu displays a list of menus that you can lock. If the Time item is set to Locked, you have to enter the PIN when accessing the Time menu. If you enter a wrong number, you cannot use the menu. To release a locked item, set it to Unlocked.

4.4 Options for recording

To set the options for recording, select the Settings > Recording menu.

To enable the time-shift function, you should set the Time Shifting option to anything other than Disable. The available range for this option is 30 minutes to 5 hours. You will have the latest of the current programme as long as the duration specified at this option.

You can record a programme into both an external and the built-in hard drive. If you want to record a programme into an external hard drive, set Recording Drive option to External; otherwise, set this option to Internal. If you set the Time Shift Storage option to Enable, the time-shifted programme will be saved in the TimeShift folder of the hard drive.

You can set the duration of the timer recording. Set the Timer Recording Duration option as you desire. Its available range is 10 minutes to 3 hours.

Time padding is the feature of adding extra recording time to the beginning or end of a programme, so that you do not miss any part of the programme. Set the Timer Record Padding option as you desire.

You can adjust the duration of the instant recording. Set the Instant Recording Duration option as you desire. Its available range is 30 minutes to 5 hours.

4.5 Options for playback

To set the options for playback, select the Settings > Playback menu.

If you want to play back a recorded file from beginning, set Starting Position option to Beginning. To play back a recorded file from the part where you were watching, set this option to Continuing.

If you want to enjoy more levels of playback speed, set the Trick Mode Level option to 2x, 4x, 8x, 16x, 32x, 64x, 128x; otherwise, set it to 4x, 16x, 64x, 128x.

If you have subtitle files such as .smi, .sub, .idx, and .srt, the digital receiver can also display them. The Media Subtitle item provides some options for video subtitle. When you play back a video file with a subtitle file, if the subtitle does not match the video, then you can synchronise them by adjusting the value of the Sync option. In addition, you can change the colour and size of subtitle by setting the Font Color and Font Size options to one you prefer.

4.6 Options for on-screen display

To set the options for the on-screen display (OSD), select the Settings > OSD menu.

To adjust the transparency level of the OSD, set the OSD Transparency option as you desire. Its available range is 0 to 50 percent.

To adjust the display time of the information box, set the Info Box Display Time option as you desire. Its available range is 1 to 30 seconds. If you set this option to No Info Box, the information box will not be displayed when you switch services.

However, pressing the [i] button will display the information box. If you set this option to Never Hide, the information box will always be displayed. For the information box, see §5.2.3.

If any service's name is too long to fit the width of the service name column on the services list screen, you can get it to scroll by setting the Text Scroll option to anything other than Disable. With the choice of Full Scroll, it will be fully scrolled until its end disappears; with the choice of Part Scroll, it will be scrolled only to its end.

4.7 Options for the front display

To set the options for the front display, select the Settings > Front Display menu.

The front display shows the currently viewed service's number and name. If any service's name is too long to fit the width of the service name column, you can get it to scroll by setting the Main Display Scrolling option to anything other than Disable. With the choice of Unlimited, it will be repeatedly scrolled; with the choice of Once, it will be scrolled only once.

4.8 Options for Photo Album

You can change a time interval and effect of slideshow in the photo album.
To change the time interval of slideshow, select the Settings > Miscellaneous menu, and then set the Slideshow Time Interval option as you desire. Its available range is 3 to 10 seconds.

4.9 Options for standby mode

You can have the current time displayed on the front display in standby mode. Select the Settings > Miscellaneous menu and set the Standby Mode options as desired and press the OK button.

Chapter 5

Every Day Use

5.1 Volume control

Use the VOL- and VOL+ buttons to alter the volume to a comfortable level.

5.2 Watching television

To change services, press the CH∧ or CH∨ button. In addition, you can switch to your desired service by entering its service number with the numeric buttons.

5.2.1 The services list



To view the services list, press the OK button. On the services list, you can see the service information as follows:

- Service number and name
- Multiplex information

To select a desired service, put the highlight bar on its entry with the

▲ or ▼ button and press the OK button, then the selected service will be presented.

Pressing the ◀ or ▶ button skips over 10 entries up or down. Entering a service number with the numeric buttons puts the highlight bar on its entry.

You can switch between the television services list and the radio services list by pressing the button.

5.2.2 The favourite service list

You can select a service on a favourite list as well as on the services list.

To display the favourite list, press the F2 button at the service list screen. For the service list, see §5.2.1.

To select a favourite list, put the highlight bar on a desired favourite group list and press the OK button, then the selected favourite group's services will be listed.

To see how to edit the favourite list, refer to §6.1.

To select a favourite service, put the highlight bar on a desired service and press the OK button, then it will be displayed. To select another group, press the button.

After you have selected a favourite service, if you then switch to another service using the ▲ or ▼ button, it will be also another favourite service of the selected group. The digital receiver will remind you what group you have selected by displaying its name at the top right of the screen whenever you switch services.

To return to the service list, press the F1 button. Besides that, you can add or delete a favourite group or service. To add a new favorite group, press the F1 button to display additional options, and then select Add New Favorite Group. To add the service you are currently watching into a favourite group, press the F1 button to display additional options, and then select Add this service item.

To remove the currently highlighted favourite grop or service, select Delete item in the additional option box, then you get asked for confirmation; with the choice of Yes, it will be removed.

5.2.3 Viewing programme information

Pressing the [i] button displays the information box, on which you can see all of the following:

- Service number and name
- Signal level and quality
- Programme name
- Programme classification sign
- Programme summary
- Broadcasting time
- Current time

In addition, you might see the following symbols:

- Subtitle symbol ([—]) if subtitle tracks are provided on the current programme.
- Dolby Digital symbol (DD D) if a Dolby Digital audio track is provided on the current programme.
- Lock symbol (🔑) if the current service is locked.

Pressing the [i] button once more displays detailed information about the current programme. To hide the information box, press the (EXT) button.

5.2.4 Selecting audio tracks

Some programmes are provided with audio tracks in one or more languages. Pressing the (🔊?) button displays available audio tracks. Once you select an audio track, that track will be heard. In addition, you can enjoy audio tracks in four sound modes: Stereo, Mono, Left or Right.

5.2.5 Selecting subtitle tracks

Some programmes are provided with subtitle tracks in one or more languages. If the current programme provides subtitle tracks, the subtitle symbol ([—]) will be marked on the information box. Pressing the (💬) button displays available subtitle tracks. Once you select a subtitle track, it will be displayed.

5.3 Viewing electronic programme guide

The Electronic Programme Guide (EPG) shows the current and scheduled programmes that are or will be available on each service with a short summary for each programme.



Pressing the EPG button displays the electronic programme guide, on which you can see the following:

- Scheduled programmes
- programme summary
- Broadcasting date
- Broadcasting time

To see detailed information of a desired programme, put the highlight bar on the programme with the ◀ or ▶ button and press the *i* button. To switch to another service, press the ▲ or ▼ button.

You can travel over previous days with the F2 button, and can travel over next days with the F3 button.

To see the programme guide for radio broadcasts, press the button. To switch it back, press the button again.

Pressing the F1 button will rearrange the form, swapping the columns and rows. To switch it back, press the F1 button again.

You can make a timer recording on the electronic programme guide. See §7.1.3 for detailed description.

5.4 Using time-shift

You can pause and resume a live television programme, and even rewind and replay it. When you are watching a programme and you miss something, you can rewind and replay it. Or when your attention is needed elsewhere, you can pause a live TV and resume a short time later without losing any of the programme.

When you do this, you are no longer watching the live programme, instead you are watching a delayed presentation. This is called time-shifted television. You can skip commercials until you catch up to the live broadcast.

In order to use the time-shift feature, set the Time Shifting option to desired duration of time. Then the digital receiver will archive the programme as much time as you set in the option. See §4.4.

The time-shift will be reset each time you change to another service. With the time-shift, the following operations are possible:

- To go back in time, hold down the F3 button; to go forward, hold down the F4 button. The progress bar is displayed momentarily with a preview window.
- You can navigate using the progress bar, refer to §7.3.1.
- You can jump backward and forward by pressing the F4 and F3 buttons. You can change the jump time at the Jump Time Interval option. See §4.5.
- You can change playback speed. See §7.3.2 for slow motion. For fast motion, see §7.3.3.
- To check your current position in time-shift, press the *i* button. The time difference compared to live programme is displayed momentarily in top right corner of the screen. A value of −02:00 means two minutes behind the live programme.
- To make a recording of the time-shifted programme,, see §7.1.4.
- To end time-shift, press the EXIT button. The live programme will be displayed.

NOTE

You can adjust some options for time-shift. Refer to §4.4.

Chapter 6

Organising Services

6.1 Editing the favourite lists

You can make your own favourite service lists. In fact, you can define multiple favourite service lists, each being a 'group' of chosen services.

Select Installation > Edit Favorite List menu. You should see a screen like the left figure. There are three columns:

- Group name (left)
- Favourites list (centre)
- Services list (right)

The services list contains all available services, whereas the favourites list contains only chosen services that have been added to the highlighted group. As you move the highlight bar up or down on the group list, favourite services belonging to the highlighted group get shown in the favourites list.

NOTE

To load guide, go to the specific channel, press the GUIDE button, then the guide will populate. Do this to every single channel upon starting up PVR.

You can add up to 30 groups. To add a new group, select the NEW item in the group list, then the on-screen keyboard appears.

To rename a group, put the highlight bar on the group entry you want and press the F2 button, then the on-screen keyboard likewise appears.

To delete a group, put the highlight bar on the group entry you want and press the F3 button, then a message box appears, asking you for confirmation. With the choice of Yes, it will be deleted.

You can add a favourite service to a group by taking the following steps:

1. Put the highlight bar on a desired group entry in the group list and press the OK button to select it. The highlight bar then moves to the services list.
2. To add a service to the selected group, put the highlight bar on a desired service entry and press the OK button. The selected service entry gets added to the favourite list. Repeat this step to add more entries.
3. Press the F1 button, and the highlight bar gets moved to the favourite list. You can delete a favourite entry with the OK button.
4. To select another group, press the F1 button again, then the highlight bar gets moved to each column.

Furthermore, you can rearrange a group's favourites by moving a favourite entry. To move a favourite entry, put the highlight bar on the favourite entry you want and press the F2 button. Press the ◀, ▶ buttons or ▲, ▼ buttons to move it to a desired place and press the OK button. To add radio services, press the TV/R button, then radio service entries get listed in the services list. To recall the television services list after adding radio services, press the TV/R button again.

As to how to use the favourite service lists you organised, refer to §5.2.2.

Chapter 7

Recording and Playback

You can record TV programmes into an external hard drive as well as the built-in hard drive.

NOTE

To use an external hard drive, you must connect the external hard drive to the USB port of the digital receiver. You cannot play back the recordings with a regular MPEG player on your computer because they are formatted differently from the standard MPEG format. Visit http://www.kmplayer.com where you can find an MPEG player able to play them back.

CAUTION

Do not disconnect the external hard drive while recording or playing back. It may cause damage to recorded programmes. You should disconnect the external hard drive in standby mode only.

Avoid transferring files while the unit is set to record. This recorder can record four channels simultaneously, however, this is controlled by the channel frequency. Each channel has other programmes under the one frequency (E.g. Channel Nine has 9, 9HD, GO, GEM) (Channel ABC has ABC News 24, ABC1, ABC2, ABC3, etc.). This recorder can record four programmes locked on two channel frequencies simultaneously. (E.g. 10.TEN Digital plus 11.One HD and 90.GEM plus 99.Go!) While recording the above combination of programmes you can also playback a pre-recorded show.

7.1 Recording a programme

Once a recording gets started, a symbol like the left figure will be displayed at the top right of the screen for a few seconds.

When you are watching a different service from the service being recorded, you will see a number on the centre of the symbol, this indicates the order that the recording has started. When you record two different channels from two different stations, what you are actually doing is locking each tuner to two separate station bandwidths.

For example, if you record channel 7TWO and channel 9 Digital, you have locked the first tuner into all the channels from 7 which includes: 7 Digital, 7 Digital 1, 7TWO and 7Mate. While on the second tuner you have locked in all the channels from 9 which includes: 9 Digital, Gem and Go.

With this in mind, while the above two channels (eg. 7TWO and 9 Digital) are being recorded, you can watch a third channel which can be only one of the following: 7 Digital, 7 Digital 1, 7Mate, Gem or Go.

The same can be said for recording for four channels (eg. 7TWO, 7Mate, 9 Digital and Go). You can watch an additional channel which can be only one of the following: 7 Digital, 7 Digital 1 or Gem.

CAUTION

Do not move the digital receiver nor pull out the power plug while it is running. It may cause damage to recorded programmes. Topfield is not responsible for damages inflicted on files that are stored on the hard drive.

7.1.1 Instant recording

To instantly record a programme you are watching at present, press the ⦿ button.

Pressing the ⏸ button will not pause the current recording like it does with a video recorder. Instead, pressing the ⏸ button will pause the live show and begin time-shifting within the current recording even with the Time Shifting option disabled. In short, it is still possible to pause a recording, but literally recording continues in the digital receiver.

After a recording has started, pressing the ⏺ button displays a menu like the left figure, in which you can set the recording duration.

To specify an arbitrary recording duration, set the Duration option as you desire with the ◀ or ▶ buttons and press the OK button; the recording will end at the specified time.

If the information about the next programme is provided by the electronic programme guide, the After this program and After next program options will be enabled. Once the After this program option is selected, the current recording will stop at the time when the current programme is scheduled to end. Likewise, once the After next program option is selected, the current recording will stop at the time when the next programme is scheduled to end.

To stop recording, press the ⏹ button; then a box like the left figure appears, which shows the programmes currently being recorded. Select recording by using navigation buttons then press OK button to stop the recording.

While a recording is going on, you can watch or record another service. To additionally record another service, switch to the service you want to record, and press the ⏺ button. Once a recording is started, it is put on the recorded programme list even though it is not finished yet. The recording file is named the program name if available or after its service name with a suffix of a number. To view the recorded programme list, press the ☰ button or alternatively select the PVR > Recorded Program menu. See §7.2 for detailed description about the recorded programme list.

7.1.2 Timer recording

You can set a programme to be recorded at a specific time. Even if the digital receiver is in standby mode, it will switch into active mode and start recording at a specified time. When the recording comes to the end, the digital receiver will switch back into standby mode again in one minute. However, if you press any button on the remote control or on the front panel even just one time, the digital receiver will not switch into standby mode.



To add a timer recording, select the PVR > Reservation menu, then the timer list will be displayed. To add a new timer event, press the F1 button, and a box like the left figure appears. Take the following steps:

1. Set the Record option to On to make a recording. If this option is set to Off, the digital receiver will turn on at the specified time but not record; instead, you may record with your video recorder or suchlike in this case.
2. You may have two sources for recording, TV and radio. Set the Type option to your desired source.
3. Set the Service option to the service which provides the programme you want. Pressing the OK button on this option displays a services list, from which you can select your desired service.
4. Set the Mode option as you desire. There are five timer modes:

   One Time means literally 'One time'.
   Every Day means literally 'Every day'.
   Every Weekend means 'Every Saturday and Sunday'.
   Weekly means 'One day every week'.
   Every Weekday means 'Every Monday to Friday'.

   If your favourite programme is broadcast at weekends and you wish to record every episode of the programme, set the Mode option to Every Weekend.
5. Set the Date option to a desired date, on which the digital receiver will turn on. The date format is *day/month/year-day of the week*.

Set the Start Time option to a desired time, at which the recording will be started. The time format is *hour:minute*.

6. Set the Duration option to a desired time, in which the recording will be finished.
7. Pressing the OK button on the File Name option displays the on-screen keyboard, with which you can specify a file name for the timer recording. If you do not specify anything, it will be named after the service name.
8. To set a recording reservation with the above settings, select the OK item; otherwise, it will not be saved and will not occur.

You can also edit or delete timer events in the timer list. To edit a timer entry, put the highlight bar on the entry you want and press OK button; then appears a box in which you can change its settings in the same manner as making a new one.

To delete a timer event, put the highlight bar on the entry you want to remove and press the F2 button, then you get asked for confirmation. With the choice of Yes, it will be deleted. To delete all timer event, press the F3 button.

You can sort timer events by time with the F4 button.

7.1.3 Scheduling recordings using the programme guide



If the electronic programme guide is properly provided, you can make timer events on it. The instructions on how to make timer recordings using the electronic programme guide are as follows:

1. Press the GUIDE button to display the electronic programme guide.
2. Select a programme you want to record with the navigation buttons.
3. To make a timer event without recording, press the OK button; the letter **P** is displayed. To make a timer event with recording, press it once more or alternatively press the ⏺ button, then the letter **R** is displayed.
4. Pressing the OK button once more will cancel the timer.

Intelligent Recording(IR)

Once you choose a show in the program guide and select Intelligent Record, it not only records the selected show, but also makes timer recordings for all other episodes of the show that can be found on the EPG.



Press the GUIDE button to display the EPG and highlight a show you want to record with the navigation buttons. To make intelligent recording, press the F4 button on the selected show, then the letter IR is displayed in blue circle.

At the same time you set the IR on your favorite show, the receiver will automatically detect the same service name on the EPG. And then, on all other episodes of the show, the letter IR in gray circle will be displayed that indicate the entire series of the show are automatically scheduled to be recorded. If you want to cancel the timer, press the OK button.

NOTE

You can check the reservation list by pressing the ⏭ button on the EPG. IR is applied only to the shows that are properly provided on the EPG. *quadrecordingYou can record up to 4 programs that start at the same time simultaneously with IR. Intelligent recording timers cannot be adjusted. If you would like to extend the duration of a intelligent recording time you will need to add timer padding. You can find this under menu/Settings/Recording. Timer padding will automatically add 1 - 30 minutes to the start or end of all shows set to record.

7.1.4 Recording a time-shifted programme

While watching a programme with time-shift, you can record it by performing the following steps:

NOTE

The whole timeshift buffer is recorded as one single file on the hard drive.

1. Press the ▶ button to display the progress bar.
2. Hold down the ◀ button to move back in timeshift.
3. Press the ● button to start recording. When you get prompted to save the timeshift programme, select YES at the same time a new live recording will begin from the end of your timeshift file on the same channel.
4. If you wish to stop the live recording, press the ■ button on the remote.

See §5.4 for detailed description about the time-shift feature.

7.2 File archive

When a programme is recorded, it is stored as a file on the hard drive of the digital receiver. You can select a recording to play back from the recorded programme list.

Select the PVR > Recorded Program menu or alternatively press the ▤ button to display the recorded programme list. The file information is comprised of the following elements: file number, file name, recording time, running time, file size and so on.

You can play, move, delete, rename and lock a recording file. You can also sort the recording files by file name, running time or file size. In addition, you can make a new folder.

7.2.1 To delete a recording

To delete a recording, put the highlight bar on it and press the F4 button, then you get asked for confirmation. With the choice of Yes, it will be deleted.

7.2.2 To sort recordings

To sort the recordings, take the following steps:

1. Press the F1 button to display additional options.
2. Set the Sorting option to Alphabetic, Time or Size as you want.
3. Press the EXIT button.
4. They will be sorted by the specified option.

7.2.3 To lock a recording

To lock a recording so that other persons cannot play or delete it, take the following steps:

1. Put the highlight bar on a desired recording.
2. Press the F1 button to display additional options.
3. Set the Lock option to Locked.
4. Press the EXIT button.
5. The lock symbol ( ) is displayed on it.

If you select a locked recording to play it back, you will be asked for your personal identification number.

7.2.4 To rename a recording

To change a recording's name, take the following steps:

1. Put the highlight bar on a desired recording.
2. Press the F1 button to display additional options.
3. Select the Rename option, and the on-screen keyboard appears. Change the name and save it.

7.2.5 To make a new folder

To make a new folder, press the F2 button, then a new folder named GROUP # is created. You can change its name in the same manner as renaming a recording. See above.

7.2.6 To move a recording to another folder

To move a recording to another folder, put the highlight bar on a desired recording and press the F3 button. If an external hard drive is connected to the digital receiver, you get asked to select between the built-in and external hard drive. Select Internal, then the folders are listed. Once you choose a folder, the recording is moved to it.

7.3 Playing back a recording

When a programme is recorded, its additional contents such as audio track or subtitle track are also recorded together. So you can enjoy them while playing back a recording.

The instructions on how to play a recording are as follows:

1. Select the PVR > Recorded Program menu or alternatively press the ▤ button to display the list of recorded programmes.
2. Put the highlight bar on a desired recording and press the OK button, then an option box pops up.
3. To play from beginning, set the Starting Position option to Beginning; to play from the point that you have stopped at the last time, set it to Continuing. To start playback, select the Play item.
4. To stop playback, press the ■ button.

During playback, you can enjoy the following tricks:

- To see the detailed information about the currently played recording, press the *i* button; then the information box appears and shows its file name, running time, programme information, and so on.
- To pause playback, press the ⏸ button. To resume it, press the ▶ button.
- To view the progress bar, press the ▶ button; to hide it, press the ▶ button again.
- When the progress bar is hidden, you can move to a desired scene by entering a progress percentage with the numeric buttons.

7.3.1 To navigate using the progress bar

First press the ▶ button to display the progress bar.

- To go forward, hold down the ▶ button; to go backward, hold down the ◀ button.
- If there are no bookmarks, you can jump forward by the minute set to the Jump time Interval option with the F3 button. See §4.5 for that option. Refer to §7.3.4 as to how to bookmark a position.
- To jump to the beginning, press the ⏮ button.
- To jump to the end, press the ⏭ button.
- To hide the progress bar, press the ▶ button again.

7.3.2 To play in slow motion

To watch in slow motion during a playback, press the ⏯ button. If you press it repeatedly, the playback speed changes in 4 steps: 1/2, 1/4, 1/8 and 1/16 times. To resume normal speed, press the ▶ button.

7.3.3 To play in fast motion

To watch in fast motion during a playback, press the ⏩ button. If you press it repeatedly, the playback speed changes. To resume normal speed, press the ▶ button.

You can play not only forward but also backward in fast motion. To play backward, press the ⏪ button. If you press it repeatedly, the playback speed changes. To resume normal speed, press the ▶ button.

You can change the playback speed in 4 steps (4x, 16x, 64x and 128x) or in 7 steps (2x, 4x, 8x, 16x, 32x, 64x and 128x). See §4.5.

7.3.4 To make a bookmark

You can mark favourite parts of a recording by creating bookmarks and then jump to them in sequence. Bookmarks are stored with the recording so that you can use them again afterwards. To make bookmarks, take the following steps during playback:

1. Press the ▶ button to display the progress bar.
2. To add a bookmark, press the F2 button at a desired scene, then you will see a small pointer appear above the progress bar like in the picture above.
3. To jump forward to the next bookmark, press the F3 button.

7.4 Copying a recorded file

You can copy a recorded file by performing the following steps:

1. Start playback of a recorded file you want.
2. Move to the scene from where you want to start the copy using the ◀ or ▶ button.
3. Press the ⏺ button and it will be copied as a new file which is named after the original recorded file with a suffix of 'COPY' and a number.
4. To stop copying, press the ⏹ button.

vThe transcoded file name will start with [Transcode] and the original file name.

7.5 Formatting the hard disk

If a new hard disk is installed, it must be formatted before using. Because the Topfield unit does not recognize unformatted hard disk. You can delete all contents stored in the hard disk by formatting it.
Select the Installation > System Recovery > Format Hard Disk menu, and then select the hard drive you want to format. To format the built-in hard drive, select the option to Internal;
otherwise to format the external hard drive which is connected to the digital receiver, select the option to External. With pressing the OK button, you get asked for confirmation. Formatting will start with the choice of Yes. Select the Installation > System Recovery > Format Hard Disk menu. With pressing the OK button, you get asked for confirmation. Formatting will start with the choice of Yes.

NOTE

The hard drive on the digital receiver will be formatted in the XFS file system.

Chapter 8

Accessing via Network

NOTE

The following section describes complex functions that should only be used by owners with advanced computer knowledge.

This digital receiver provides features of web service and FTP service, by which through the network you can make scheduled recordings, or transfer recording files to your computer.

Here you need a router, which will connect the digital receiver to your computer or to the Internet. If you want to have a wireless connection, you need a wireless router.

To use the network features of the digital receiver, you should take the following steps:

1. Configuring your router for the digital receiver.
2. Configuring the network settings on the digital receiver.
3. Accessing the home page of the digital receiver. Refer to §8.3 for detailed description about things you can do by using the web service of the digital receiver.
4. Accessing the FTP Server of the digital receiver.

NOTE

The web server and FTP server of the digital receiver do not work in standby mode. So it must be powered up at all times if you wish to use the web service at any time.

8.1 Configuring the router

In this section, the setup program of *WRT54G*, which is a router manufactured by *Linksys*, will be referred to as an example of how to configure the router for network access.

NOTE

For detailed description about how to set up the router, refer to the manual of your router.

8.1.1 To access within the local area network

Once your router is powered up, a local area network gets created whether or not it is connected to the Internet.


Local IP Address : 192 . 168 . 1 . 1
Subnet Mask : 255 . 255 . 255 . 0
DHCP Server : Enable Disable
Starting IP Address : 192.168.1. 100
Maximum Number of DHCP Users : 50
Client Lease Time : 0 minutes (0 means one day)
WINS : 0 . 0 . 0 . 0

You can let the router automatically assign a dynamic IP address to the computers or devices connected to the network by enabling the DHCP server of the router. In this case, you can access the digital receiver with the IP address which is assigned to the digital receiver by the router.

If the digital receiver reboots, a new dynamic IP address will be assigned to it. You had better assign a static IP address to the digital receiver to avoid this inconvenience. As to how to assign a static IP address, refer to the manual of your router; as to how to specify a static IP address on the digital receiver, see §8.2.

8.1.2 To access over the Internet

When you are away from home, you can access the digital receiver inside your home if your router is configured to route access to the digital receiver by means of port forwarding. Via this feature, your router will lead you to the digital receiver when you access your router with its IP address.

Port Range					
Application	Start	End	Protocol	IP Address	Enable
PVRHTTP	80 to	80	Both	192.168.1. 161	☑
PVRFTP	20 to	21	Both	192.168.1. 161	☑
	0 to	0	Both	192.168.1. 0	☐
	0 to	0	Both	192.168.1. 0	☐

Your router may be assigned to a dynamic IP address by an Internet service provider. So if the router has rebooted, you cannot access it unless someone in your home can inform you of the changed IP address. However, many routers support Dynamic Domain Name System (DDNS) service, which can settle this problem. The following image is an example of one such DDNS service provider.



If you use a DDNS service, you can access your router with a domain name. The instructions on how to use the DDNS service are as follows:

1. Make an account on a web site providing DDNS service, which should be supported by your router.
2. Configure your router with the account so that it can communicate with the web site.

Whenever a new dynamic IP address is assigned to the router, it will

inform the DDNS service provider of the new IP address. This makes it possible that you access the router with a domain name at any time.

8.2 Network setup

8.2.1 For a wired connection

1. Connect your Ethernet cable from your router to the Topfield recorder.
2. Press Installation > Network Setting > IP Setting.
3. It is recommended to use a dynamic IP address by the router therefore select DHCP as the connection type. However if a static connection is set then please refer to your router for an IP address, Subnet Mask, Gateway, Primary DNS, Secondary DNS.
4. Scroll down to activate profile and press the OK button on the remote.
5. A successful connection will populate all the IP settings and the Level/Quality bars on the TV screen will show a high percentage level.

8.2.2 For a wireless connection

1. Connect the USB wireless dongle to the USB port on the PVR.
2. Press Installation > Network Setting > IP Setting.
3. Select Wired/Wireless LAN. Then select Wireless as the preferred connection.
5. Select AP list and press OK. A list of available networks will be shown, then select your personal network.
6. Once network is selected choose the security mode WPA / WPA2 / WEP. Select your WPA / WPA2 / WEP algorithm according to your router setting.
7. Entre the pre-shared key which is also known as your network password. Network password must be exactly the same as your router setting including Upper/Lower case and any numbers used.
8. A successful connection will populate all the IP settings and the Level/Quality bars on the TV screen will show a high percentage level. If the fields are not populated check the password and any security settings.

NOTE

After selecting activate please allow up to 5 seconds for fields to populate. Most routers can be accessed via a web browser. Refer to your Router user guide on how to access router setting.

8.3 Accessing the web server

To Access to the web server, set the Installation > Network Setting > Web Server option to Enable.

Select the Installation > Network Setting > User Info menu. At this time, you have to enter Personal Identification Number (PIN). Then set the User ID and Password options as you desire. And select OK to save the settings. When you access to the web server, you will be asked for the account that was made with these options.

In way of the web server of the digital receiver, you can do the following:

- Download recording files.
- Create new recording timers.
- View information about the programme currently being recorded.
- View the system information of the digital receiver.

To access the digital receiver's home page through your web browser, enter its IP address, or domain name if you use a DDNS service. For the DDNS service, refer to the user manual of your router.



You cannot only download but also upload recording files or MP3 files in the File Management page. However, if you wish to download or upload a file of which size is 2 gigabyte or more, it is recommended using the FTP server rather than the web server.



NOTE

The maximum number of user connections is one. This means that you cannot access the web server while someone else is occupying it.

8.4 Accessing the FTP server

To Access to the FTP server, set the Installation > Network Setting > FTP Server option to Enable.

Select the Installation > Network Setting > User Info menu. At this time, you have to enter Personal Identification Number (PIN). Then set the User ID and Password options as you desire. And select OK to save the settings. When you access to the FTP server, you will be asked for the account that was made with these options.

NOTE

You can access the FTP server with an anonymous account. However, with an anonymous account you can only download files. You cannot upload files.

You need an FTP client program to access the FTP server of the digital receiver.



You can log into the FTP server with the user name and password specified in the Installation > Network Setting > User Info menu.


SmartFTP v1.5 - Unlicensed - [TF6000PVR : guest]
FTP Commands View Tools Favorites Window Help
Address TF6000PVR Login guest Password Port 21 Anonymous
192.168.184.167
DataFiles
MP3
dance
GROUP 01
pop
ProgramFiles
Name Size Date
Parent Folder
dance 2005-04-22 오전 12:00
GROUP 01 2005-03-20 오전 12:00
pop 2005-04-22 오전 12:00
Linkin_Park_-_Meteora_-_01_-_Foreword_-_Abyss.mp3 314KB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_02_-_Don't_Stay_-_Abyss.mp3 4.30MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_03_-_Somewhere_I_Belong_-_Aby.mp3 4.69MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_04_-_Lying_From_You_-_Abyss.mp3 4.00MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_05_-_Hit_THe_Floor_-_Abyss.mp3 3.75MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_06_-_Easier_To_Run_-_Abyss.mp3 4.67MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_07_-_Faint_-_Abyss.mp3 3.70MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_08_-_Figure.09_-_Abyss.mp3 4.51MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_09_-_Breaking_The_Habit_-_Aby.mp3 4.48MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_10_-_From_The_Inside_-_Abyss.mp3 4.01MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_11_-_Nobody's_Listening_-_Aby.mp3 4.08MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_12_-_Session_-_Abyss.mp3 3.31MB 2005-03-20 오전 11:56
Linkin_Park_-_Meteora_-_13_-_Numb_-_Abyss.mp3 4.29MB 2005-03-20 오전 11:56
PASV
227 Passive mode OK (192,168,184,167,16,6)
Opening data connection to 192.168.184.167 Port: 4102
LIST -aL
150 Accepted data connection from 192.168.2.7:2126
226 18 matches total
1670 bytes transferred. (7.76KB/s) (210 ms)
Log Session Queue /MP3 16 Object(s) Total: 50.3MB 00:00:17
192.168.184.167

NOTE

The maximum number of user connections is one. This means that you cannot access the FTP server while someone else is occupying it.

Chapter 9

Topfield Application Program

If you are good at programming with *C/C++* language, you may make an executable program to run on the digital receiver. We call user-made programs TopfieldApplication Programs (TAP).

For TAPs writers, Topfield provides two versions of *gcc* compilier and TAP API (Application Program Interface) libraries that are available from Topfield's website, http://www.i-topfield.com. One is *Linux* version, and the other is *Cygwin* version.

Cygwin is a Unix-like environment and command-line interface for *Microsoft Windows*.

Your TAPs will be run with the following conditions:

- A TAP's file extension must be *tap*; if it has any other extension name, it will be ignored.
- TAPs must be situated in the Program Files folder; if they are placed in any other folder, they will be ignored.

Before you start the TAP, you will need to load the TAP file into the program file menu by doing the following:

1. Press the ▤ button and then the F3 or F4 button to display the program files list.
2. Insert the USB with the TAP file into your unit.
3. On the remote, press the SAT button. Press the OK on top of the name of your external hard disk.
4. Use the navigation keys to highlight the TAP file.
5. Press the yellow button on top of the file.
6. It will prompt you that the file will be moved into the program files folder. Press OK.

NOTE

If you would like the TAP to start when the unit starts up, move the TAP file into the Auto Start folder in the Program Files menu.

To run a TAP in the digital receiver, take the following steps:

1. Press the ▤ button and then the F3 or F4 button to display the program files list.
2. Place the highlight bar on a program file you want to run, and press the OK button to start it up.
3. If it is a running-in-the-background program, its entry in the list gets marked in green when it starts. You may have several programs run in the background at a time.
4. To stop a program running in the background, place the highlight bar on its entry in the list, and press the OK button; otherwise you can stop it with the EXIT button.

The figure on the left is a screenshot of *ScreenCapture.tap*, with which you can capture screen in *bmp* format from the digital receiver. Not only this TAP but a lot of sample TAPs are available in the TAP API.

By the way, the digital receiver will not show the list of the screenshots saved by the *ScreenCapture.tap* because *bmp* files are supposed to be

ignored by the digital receiver. So, to view the screenshots, you need to transfer them to your computer via FTP.

If you want to have a program automatically run when the digital receiver starts up, then move the program file to the AutoStart folder. If you want to abort the execution of it, press the 0 button at start-up.

NOTE

Topfield is not responsible for any results caused by a use of unauthorised TAPs.

Chapter 10

Firmware Update

The digital receiver has a stable and convenient firmware to use. However, once in a while a new firmware may be released to improve the digital receiver. You can get the latest firmware and the firmware update tool, which runs on most versions of Windows, from the Topfield website http://www.i-topfield.com or

10.1 From a memory stick

If you have a USB memory stick, you can update the firmware from it by taking the following steps:



1. Download a new firmware from the Topfield website.
2. Copy the firmware file to your memory stick.
3. Insert the USB memory stick into the USB port on the digital receiver.
4. Select the Installation > Firmware Upgrade > USB Firmware Upgrade menu, and the files in the USB memory will be listed.
5. Place the highlight bar on the right firmware file and press the OK button, and a countdown will be displayed on the front display of the digital receiver.
6. When the message of 'END' appears, restart the digital receiver.

10.2 From the firmware server via the Internet

You can update the firmware from the firmware server which is being run by Topfield via the Internet. Make sure that the digital receiver is connected to your router before configuring the network settings on the digital receiver.

NOTE

For detailed description about how to set up the router, refer to the manual of your router.



Select the Installation > Firmware Upgrade > Network Firmware Upgrade menu. You should see a screen like the left figure.

To enable the digital receiver to update the firmware automatically when a new firmware is available, set the Automatic Upgrade option to Enable. Otherwise if you want to do that by yourself, select the Start firmware upgrade option, then you get asked for confirmation. With the choice of Yes, it will check up whether a new firmware is available, and it starts firmware update if any.

Appendix A

Troubleshooting

List of Symptoms

No power / No front display 55
I have connected my Topfield unit to the TV but getting no picture 55
When the Service Scan is finished I get zero channels 55
Getting pixilated images on the my Television 55
Can not receive or adjust sound through the Topfield unit 56
Can not rewind live Television 56
The Free to Air Guide is blank 56
Can not set the correct aspect ratio 56
Lost part of my show because it went longer then the set time . . 56
Can not get a network connection 57
Can not connect my external HDD 57
Can not see the time shown on the front of the Topfield unit . . . 57
My Topfield recorder doesn't go to standby after instant recording 57
Cannot view guide content 57

Before you call a repair person for your Topfield product, check the list of possible problems and solutions.

No power / No front display

- Make sure the main switch on the back of the Topfield unit is switched to ON.
- Properly insert the power plug into the power socket.
- If the power outlet is controlled by a switch, make sure the wall switch is ON.
- Remove the power plug from the wall and wait 10 seconds, then plug back in.
- Plug another appliance into the outlet, if the other appliance doesn't work then have a qualified electrician repair the outlet.
- Plug the Topfield unit power code into a different outlet.

I have connected my Topfield unit to the TV but getting no picture

- The connection must be via an AV output out of the Topfield unit to an AV input of the TV.
- Check that you are in the correct AV setting on the TV. For example if you connected the Topfield unit to AV2 on the TV make sure you set your TV with the TV remote to AV2 before the Topfield unit can be used.
- Press the (VF) button on the remote and set to the correct resolution.
  576i/576p/720p/1080i/1080p. You may need to press the (VF) button multiple times to cycle through all the different formats. All formats will be displayed on the front screen of the Topfield unit.

When the Service Scan is finished I get zero channels

- Check that there is a signal coming from the antenna by connecting it directly to the TV or another device.
- You must have signal strength between 50%–90%
- Indoor antenna is not recommended as the signal is not enough to display channels when a service is scanned.

Getting pixilated images on the my Television

- Check the plug on the Topfield unit and on the wall making sure that it's a tight connection.
- Check that there is a signal coming from the antenna by connecting it directly to the TV or another device.
- You must have signal strength between 50%–90%

Can not receive or adjust sound through the Topfield unit

- Adjust volume using the VOL- or VOL+ on the Topfield remote.
- Use the TV remote to adjust the sound to approx 50% then use the Topfield remote to adjust volume.
- Check the connection between the TV and the Topfield product.
- Make sure you are in the correct AV on the TV

Can not rewind live Television

- Make sure that Timeshift is enabled, Settings > Recording.
- Check that Hard Disc Drive is working by playing back a previous recorded program.

The Free to Air Guide is blank

- Move to every channel and give the recorder a few minutes to populate the guide for each channel.
- Factory reset and re-scan all the services in the Installation part of the MENU.
- Check the broadcaster sends a Free to Air guide for that service.

Can not set the correct aspect ratio

- Change the aspect ratio on the Topfield unit by pressing the AR button on the Topfield remote. 16:9/4:3
- Check the aspect ratio on your TV. Refer to the user guide of your TV for information about this procedure.
- Check the broadcast of the program. For example some programs are only broadcasted in 4:3

Lost part of my show because it went longer then the set time

- When setting a Reservation add an extra few minutes to the Duration to cover for programs going over the predicted time.
- When recording off the Free to Air guide press the ⦿ button twice on the Topfield remote and adjust the duration to cover for programs going over the predicted time.
- Adjust the Padding in the Settings > Recording > Timer Record Padding [Rear]. Adjust according to personal preference.

Can not get a network connection

- Make sure you are using a Router and not a Modem.
- You can only establish a connection by using the Network cable directly to the Topfield unit OR by using a USB wireless dongle.
- You are using a 3rd part USB wireless dongle.
- Your router settings are not set up correctly in the Topfieldunit.
- Check connection of Ethernet cable and USB wireless dongle, making sure they are a tight fit in the socket.
- Restart Router and try again.

Can not connect my external HDD

- Make sure external HDD is formatted in NTFS, then reformatted to the system when it is connected. This will ensure that the hard drive is ready to use and the full capacity is available.
- The HDD must not be more then 1000 GB (1 TB).
- You must make sure that the external HDD is self powered.

Can not see the time shown on the front of the Topfield unit

This can be adjusted in the Settings > Miscellaneous > Standby Mode, from Passive to Active.

My Topfield recorder doesn't go to standby after instant recording

When an instant recording has been activated the recorder will need to stay on until the recording finishes.
To place the recorder into standby after the recording has finished press the Power button on the remote control during a recording and the following message will be displayed "RECORDER NOT FINISHED, DO YOU WANT TO POWER OFF?".
Move the green tab to YES and leave the recorder uiON, but do not execute the function. The television may be turned off and the recorder will go into standby (sleep mode) when the recording has finished.

Cannot view guide content

Perform a factory reset and service search to allow the unit to restart the guide. Be sure to save your settings in the Installation section before applying a factory reset.

Manufactured under license from Dolby Laboratories. “Dolby” and the double-D symbol are trademarks of Dolby Laboratories.

Correct disposal of this product

This marking shown on the product or its literature indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product or their local government office for details of where and how they can dispose this product for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

At any time during the life of a product Topfield Co., Ltd. may change or modify the hardware or software on any product to introduce new features or improve the functionality of the product.

Copyright © 2012, Topfield Co., Ltd. All rights reserved.

English version

http://www.i-topfield.com

Dec. 2012